



X1070
pin 9: F33 5A HOT IN RUN OR START
pin 14: F45 7.5A HOT IN RUN OR START

X1071
pin 8: F31 5A HOT AT ALL TIMES